LED Flash Conversion for Tecpro Beltpacks

27-891 Switch with LED

Typical Tecpro Beltpack

1   Remove flash switch cover, (pulls off).
2   Unscrew back panel screws (x 4).
3   Slide back panel and PCB assembly out.

27-891

Location of 'old' flash switch

1 Flip over PCB assembly.
2 Locate six solder pins of existing switch.
3 Desolder pins.
4 Locate new switch & solder into place.
5 Re-assemble unit

6 solder pins of existing switch

27-891 Showing PCB pins