


2. If desired, adhere the supplied hook and loop strips around the microphone grille, approximately one inch from the base of the grille (as shown above) to hold new windscreen in place.



Install new windscreen by stretching over the hook & loop strips, then
squeezing at the base of the windscreen to adhere to them. No strip
inside the windscreen is needed, as the windscreen itself will adhere
to the hook & loop. To remove, grip at the base of the windscreen and
pull while twisting.



SHURE Incorporated http://www.shure.com
United States, Canada, Latin America, Caribbean:
5800 W. Touhy Avenue, Niles, IL 60714-4608, U.S.A.
Phone: 847-600-2000 U.S. Fax: 847-600-1212 Intl Fax: 847-600-6446
Europe, Middle East, Africa:
Shure Europe GmbH, Phone: 49-7131-72140 Fax: 49-7131-721414
Asia, Pacific:
Shure Asia Limited, Phone: 852-2893-4290 Fax: 852-2893-4055