

Technical Data Sheet

SLAVE SWITCHER UNIT CS6 INSTRUCTIONS FOR USE

42-662 EMO Slave Switcher Unit CS6

WARNING: TO AVOID ELECTRICAL SHOCK READ THESE INSTRUCTIONS CAREFULLY.

ISOLATE ALL MAINS POWER BEFORE WORKING ON THE UNIT

These instructions should be read in conjunction with instructions supplied with the master unit (CM6).

Control Input

Low voltage control inputs marked 1 and 2 should be connected as follows:

Terminal 2 is the control input and should be connected to the chosen output terminal on the master unit (CM6).

If the slave is the first unit then this terminal should be connected to terminal 1 on the master, if the second then connection should be to terminal 2, etc.

Terminal 1 is the common control input and should be connected to terminal 9 or 10 on the master unit.