

MS Series

The MS-Series music stand light is designed to attach to any standard music stand with a flat-edge. The light can be mounted on the top or the side of the stand.

In order to provide a good grip on the music stand the clamp must be adjusted to fit. Loosen the two screws on the bottom of the light and adjust the clamp opening so that it grips the surface of the stand snugly. Tighten the screws.



For more information contact Littlite at (888) 548-8548 or visit http://www.littlite.com

 $\odot 2010$ Littlite, LLC, All rights reserved. The term Littlite \circledast , the Littlite logo and Lite print logo are registered trademarks of Littlite, LLC and are not to be used without permission.

E K S н Ε Ε Hamburg, MI 48139 USA sales@littlite.com 1-810-231-9373 littlite.com littlitedirect.com