

Neutrik OpticalCON FOPS SINGLE Pulling Sock Handling Instructions

Installing the Sock



- A**
Open metal zipper and attach the strain relief on the cable as illustrated left.



- B**
Due to the strain relief being the main element for the pulling force it's important to tighten the cable tie.



- C**
Secure the attached strain relief and cable on to the opticalCON pulling sock using the Hook & Loop strip



- D**
Close metal zipper and tighten Hook & Loop strip to enhance cable retention of the entire pulling sock.



Finished Article

Neutrik OpticalCON FOPS SINGLE Pulling Sock Handling Instructions

Securing the Installed Sock on Cable Drum



A

Reel up attached pulling sock flat on to the cable drum being used.



B

Secure opticalCON pulling sock with the black hook on the metal grommet.

NOTE:

The proper length of the elastic cord can be individually adjusted according to the outer diameter of the used drum.



Finished Article